

ASSEMBLING INSTRUCTION

N-ADATT-HD HARLEY DAVIDSON MIRROR ADAPTER

WWW.BARRACUDAMOTO.COM

LEGEND

1. GRUB SCREW M8X50 PITCH 1.50
GRANI M8X50 PASSO 1.50
TORNILLO SIN CAPEZA M8X50 PASO 1.50
KOPFLOSE SCHRAUBEN M8X50 GEWINDESTEIFUNG 1.50
VIS SANS TÊTE M8X50 PAS 1.50
2. WASHER Ø 8,5
RONDELLA Ø 8,5
ARANDELA Ø 8,5
SCHEIBE Ø 8,5
RONDELLE Ø 8,5
3. DOME NUT M8
DADO CIEGO M8
TUERCA CIEGA M8
GEWÖLBTE ÜBERWURFMUTTER M8
ÉCROU BORGNE M8

